


FLOW MATERIAL



FROM STANDING AT THE VIRGIN FEED END OF THE DRUM, IF THE SLAT CONVEYOR IS ON THE RIGHT HAND SIDE.

